









FRONT





PRODUCT DESCRIPTION

Modco Modular Exhibits Modular 6 is a three-dimensional 10' x 10' pre-designed exhibit booth. Stylish and lively, Modco Modular Exhibits Modular 6 is built using tool-free perforated modular aluminum frames. Multiple size frames connect using simple toolless pin connectors. Customize double-sided stretch fabric SEG graphics for the entire exhibit. Perforations are completely covered for a flawless finish.

DISPLAY DIMENSIONS	117.375"W x 97.9"H x 117.5"D		
GRAPHIC SIZES	PANEL	SIZE	QTY
	А	40.125"W x 96.25"H	4
	В	40.125"W x 109.125"	2
	С	40.125"W x 98.75"	2
	D	118.375"W x 96.25"H	2
		TOTAL PRINTS	10

GRAPHIC MATERIAL

Dye Sub Fabric

GRAPHIC FINISHING

Silicone beading is sewn around the perimeter of the fabric graphic. Silicone beading is hidden from view once installed.

DISPLAY CONSTRUCTION

Aluminum frame and components


SHIPPING WEIGHTS & DIMENSIONS (FREIGHT ONLY)

Shipping Weight	lbs (frame & graphics in crate)
Shipping Dimensions	103"L x 44"W x 58"H (in crate)

GRAPHIC TURN AROUND TIME

5 business days after proof approval

AVAILABILITY | CA only



FRAME ONLY










PARTS LIST




(qty 1) MOD-CRVFRM-774x992



(qty 6) MOD-FRM-992x2418



(qty 1) MOD-FRM-992x1984




(qty 4) MOD-180D-CON



(qty 4) MOD-CLA-CON




(qty 10) MOD-90D-CON



(qty 4) MOD-SM90D-CON



(qty 2) MOD-CP-3100



(qty 22) MOD-CC



(qty 2) MOD-CP-774



(qty 48) MOD-PC



(qty 4) MOD-SN28MM



(qty 4) MOD-PCWP-B



(qty 2) MOD-CRV-180DCL



(qty 2) MOD-CRV-180DCR











SET UP INSTRUCTIONS





















































Graphic Install



Place graphic over the front of the frame.



Begin inserting SEG beading at each corner.



Insert the silicone beading with the fabric folded over. The silicone beading should not be exposed,



Using your fingers, push both fabric and silicone beading completely into the extrusions channel.



Continue to push in the remaining silicone beading on each side.



Check the perimeter of the frame for any excess beading that hasn't been pushed in. Graphic should be taut.